


PN32-R551-27U

INCLUDED ACCESSORIES



Remote and AAA battery (2)



TV stand (2)


ST4 screw
(12 mm length) (4)

1 INSTALLING THE STANDS OR A WALL MOUNT

How do I attach the stands to my TV? (not for wall mounting)

Place your TV face-down on a cushioned, clean surface

- 1 Align the TV stand screw holes with the holes on your TV's bottom.
- 2 Use a Phillips screwdriver and two provided screws to secure each stand to your TV.



WALL MOUNTING

How do I mount my TV to the wall?


Before you mount your TV, make sure that:

- You remove the stands if you have already installed them.
- The wall-mount bracket supports the weight of your TV.

See the instructions that came with your wall mount for more information about how to correctly mount your TV.

⚠ WARNING: Your TV has four VESA mounting holes on the back. **You must secure a wall-mount bracket to all four holes.** If you do not use all four holes, your TV may fall and cause property damage or personal injury.


Note: Wall-mount screws are not included.



FEATURES

Front

Bottom



Note: Images do not necessarily represent the exact design of your television.

2 MAKING CONNECTIONS

How do I watch TV (cable, satellite, or antenna) or connect a device such as a DVD or Blu-ray disc player or game console? How do I connect to the internet?

WHAT YOU NEED (not included)

- Phillips screwdriver
- Computer, tablet, or smart phone (to connect with a Roku account)
- Roku account and internet connection (for streaming)*

*Subscription or other payment may be required to access certain content.
IMPORTANT: Roku never charges for activation. A Roku account and internet connection are required for activation. A paid subscription or other payments may be required for some streaming app content. App availability subject to change and varies by country.

FIND YOUR USER GUIDE ONLINE!

Go to www.usca.pioneer-tv.com and search for **PN32-R551-27U**.

For Roku OS features, the *User Guide* can be found at <http://go.roku.com/tvmanual>.



Before using your new TV, read these instructions to prevent any damage. Do not plug your power cord in until all other devices have been connected.

VIDEO OPTIONS






HDMI (BEST)

Note: You can use HDMI to connect to other HDMI devices. To use ARC functionality the connected device must also have HDMI ARC. Both devices need to be plugged into **ARC HDMI** ports.

ANT/CABLE (GOOD)



Note: Connect an HD antenna or clear cable (via a wall jack).

AV (GOOD)



AUDIO OPTIONS USING HEADPHONES

USING DIGITAL AUDIO



For best audio clarity use **HDMI 1 (ARC)** for audio output. Surround sound signal from the TV/source can be compressed when using non-HDMI connections.


Note: If you need to change the digital audio format, go to **Home**, select **Settings**, and then select **Audio**. Next, select **Digital Audio Output**, then select **Digital Audio Format**, and change the setting to **PCM** or your preferred audio format.

3 TURNING ON YOUR TV


When can I turn on my TV?

WHEN YOUR TV IS IN PLACE:

- 1 Plug the power cord from the back of your TV to a power outlet.



- 2 Remove the remote cover and install the batteries.




Tip: Always replace dead batteries with two brand-new AAA batteries from the same manufacturer. Never use damaged batteries. If your remote gets hot during use, stop using and contact customer support immediately.

4 COMPLETING GUIDED SETUP

How do I activate my Pioneer Roku TV?

- 1 Press the (Power) button on your remote.
- 2 Follow the on-screen instructions on your Pioneer Roku TV by using your computer or smartphone to link to a Roku account. If you are not ready to connect to the internet now, you can still use your TV to view content accessible through other connected input sources.

Note: When powering on your TV for the very first time, the Guided Setup screens will guide you through the Wi-Fi setup steps.



Note: Wi-Fi set up screens may change.

FREQUENTLY ASKED QUESTIONS

Why do I need an internet connection?

You will need an internet connection to stream your favorite apps and for automatic software updates.


Why should I enter a payment method?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization. Roku never charges for activation.

SERVICING

Servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, we recommend you do not perform any servicing other than that contained in the operating instructions, unless you are qualified to do so.

USING YOUR REMOTE



Access the Pioneer TV User Guide

Access the online *User Guide*. Go to www.usca.pioneer-tv.com and search for your model number. Many questions regarding parts, service, and warranties can be answered by visiting the Support section of our website: www.usca.pioneer-tv.com.

Access the Roku TV User Guide

Visit <http://go.roku.com/tvmanual> for details.

Contact Pioneer TV Customer Support Center:

1-888-287-7658 (U.S. or Canada)

One-Year Limited Warranty

Visit www.bestbuy.com for details.

Need Additional help?

Check out our Support Community at www.bestbuy.com for helpful information from other Pioneer TV owners.

We're Here For You

www.bestbuy.com

For customer service, call: 1-877-467-4289 (U.S./Canada)



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress, and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 1992-2019 Dolby Laboratories. All rights reserved.

PIONEER and the Pioneer logo are registered trademarks of Pioneer Corporation, and are used under license.

Not all apps and content available in LED TV (HD).

Roku, Roku TV, the Roku logo, and the purple d-pad design are the trademarks or registered trademarks of Roku, Inc. in the United States and other countries. All other trademarks and logos herein are the property of their respective owners.

BEST BUY Distributed and warranted by Best Buy Purchasing LLC
Richfield, MN 55423
©2026 Best Buy. All rights reserved.